


Conversion Kit for Screw Capping Machine



COMPONENTS

- ① Head Bracket
- ② Middle Brackets
- ③ Machine Feed Guide
750
- ④ Hand Feed Guide
- ⑤ Main Feed Guide
750 Approx
- ⑥ Dispenser
- ⑦ Magnetic Screw Capper Adaptor
(1 per Head)

Contact **ZORK** or your preferred supplier for Installation & Set-up Details

Not all machines are alike. If the concepts in this schematic do not suit your machine please contact your local supplier or ZORK for a customized solution.

ZORK capping recommendations are subject to change without notice. Regular updates are available at www.zork.com.au

ZORK® closures that work